







BACKWALL




FRONTSTAGE



LINK 2

LINK 2



ROBE CYC F4=MODE 2	EUROLITE AUDBLINDER	EUROLITE TMH-13	SGM Idea SPOT 250	EUROLITE TMH-X5
ROBE SPIKIE=MODE 1	LED PAR	LOOK UNIQUE (toss)	ROBE LEDWASH 300	WASH 600 W
Vega Pixel Bar				

Number, **püstises asendis**, tähistab valgusti aadressi. Number, **kaldkirjas**, tähistab valgusti numbrit, mida puldil sisestada, et teda aktiveerida.

Link asub saali keskel

